

performancetrucks.net decal instructions

1. Your performancetruck.net decal is supplied in three layers. The decal itself is between a layer of backing material, and a layer of transfer. Run a squeegee or credit card over decal well to insure the decal is adhered to the transfer film.
EXTREMELY IMPORTANT!
2. Set decal upside down and remove backing material. SLOWLY!!!! (Decal will remain on transfer film, (step 1 helps insure this))
3. Line up decal in desired position.
4. Press down firmly on one side of the decal and work your way toward the other edge. Rub over the decal with a squeegee or credit card to smooth out and to remove any air bubbles.
5. After decal is placed, slowly remove the transfer film. If any of the decal starts to pull up, it has not been applied firmly enough. Press down over the decal again before trying to remove the transfer film.

NOTE

Only apply the decal to clean surface. Clean with soap and water prior to installation, and make sure area is thoroughly dry. If you use alcohol to clean the area, be sure the area is completely dry and free of any alcohol before you place/set the decal. Only apply decals in temperatures greater than 40 Degrees F.

Decals can be applied wet (**except** Chrome). If you wish to install wet, use a fine mist of water on the surface of the vehicle. This will allow more time to smooth out any air bubbles before the decal sticks. **Wait about 5 to 15 minutes before removing the transfer film with this method!!!** Do not install in direct sunlight.